



1. Dig a hole in the soil 12-15" deep and 6" wide.
 2. Bell out the bottom of the hole 12" wide.
 3. Pour concrete in half way and place your Bazoooka mount in.
 4. Make sure Bazoooka is level then proceed to fill the rest with concrete.
- Make sure Bazoooka is level throughout the process. Adjust if needed.



1. Lift Locking Plate on In-Ground barrel.
2. Place Stem into In-Ground barrel. Turn stem to lock down onto cross bar.
3. Make sure eyelet on Stem is lined up properly to the Locking Plate. Locking Plate will rest through the eyelet on the Stem.

You can use a lock of your choice to prevent theft.



1. Bore a hole 6" wide into existing concrete.
 2. Proceed to bore out the concrete 9" deep. (In-ground sleeve can rest flat on existing concrete)
 3. Pour concrete in half way and place your Bazoooka mount in.
 4. Make sure Bazoooka is level then proceed to fill the rest with concrete.
- Make sure Bazoooka is level throughout the process. Adjust if needed.